



**ASiKS-Engineering**

**User Manual**

**LIN-RS232 Module**

**Document Reference No.: UM128701**

**Version 2.0**

**Issue Date: 2019-01-15**

**This document provides detailed information about ASiKS-Engineering's LIN-RS232 Module.**

**ASiKS-Engineering  
Your Reliable Partner  
in System Engineering, Prototyping, Hardware and Software Development  
Dr. Andreas Schramm**

Pointenweg 3, 94110 Wegscheid, Germany  
Tel.: +49(0)8165/4093868  
E-Mail: [info@asiks-engineering.com](mailto:info@asiks-engineering.com) Web: <https://www.asiks-engineering.com>

Copyright © 2010 ASiKS-Engineering



## TABLE OF CONTENTS

<b>1 Introduction .....</b>	<b>3</b>
<b>2 Connectors and pinning description .....</b>	<b>3</b>
2.1 LIN connector D-SUB 09 plug (male) .....	3
2.2 RS232 Connector D-SUB 09 plug (female) .....	4
<b>3 Contact Information.....</b>	<b>4</b>
<b>Appendix A – Revision History .....</b>	<b>4</b>

## 1 Introduction

The LIN-RS232 Module shown in Figure 1 is used for easily connecting a LIN Bus to the serial Port (RS232) of e.g. a PC.

As it is passive module, no baud rate conversion or LIN Bus specific signal generation is done the module.



Figure 1: LIN-RS232 Module

This interface provides the following features:

- 9-pin D-SUB plug (male) to connect to the LIN Bus
- 9-pin D-SUB plug (female) to connect to the serial port of e.g. a PC
- Dimensions: 63mm x 34mm x 17mm
- Optimised to be used with LIN-EASYSTARTER (LinMon software, downloadable at [https://www.asiks-engineering.com/downloads\\_eng.html](https://www.asiks-engineering.com/downloads_eng.html) )

## 2 Connectors and pinning description

### 2.1 LIN connector D-SUB 09 plug (male)

Table 1 shows the pinning, functional description and electrical characteristics of the LIN connector and LIN-RS232 Module.

Pin	Symbol	Description	Min	Typ	Max	Unit
3	GND	Ground	0	0	0	V
4	NSLP*	sleep control input (active low); controls inhibit output; resets wake-up source flag on TXD and wake-up request on RXD	-0.3		+7	V
					-	mA
5	INH*	battery related inhibit output for controlling an external voltage regulator; active HIGH after a wake-up event	-0.3		V <sub>Bat</sub> +0.3	V
			-50		+15	mA
6	VCC	Voltage output	4.9	5	5.1	V
					200	mA
7	LIN**	LIN bus line input/output	-27		+40	V
8	NWAKE*	local wake-up input (active-LOW); negative edge triggered	-1		+40	V
			-15		-	mA
9	V <sub>Bat</sub>	battery supply	5	12	18	V

Table 1: Quick reference data

Note \*: This signal lines are optional. Only available if stated at ordered!

Note \*\*: Master configuration (1k PullUp), slave configuration on

## 2.2 RS232 Connector D-SUB 09 plug (female)

Standard 9-pin D-SUB connector to connect the LIN-RS232 Module to the serial communication port of e.g. a PC using a standard 1:1 straight cable.

The electrical characteristics of the RS232 Standard apply.

## 3 Disclaimer

**For damage of any kind, arising by the employment of the LIN-RS232 Module, no requirements can be made valid opposite the supplier!**

## 4 Contact Information

ASiKS-Engineering  
Dr. Andreas Schramm  
Pointenweg 3  
94110 Wegscheid  
Germany  
Tel: +49(0)8165/4093868  
E-mail: [info@asiks-engineering.com](mailto:info@asiks-engineering.com)  
Web Site URL <https://www.asiks-engineering.com>

Neither the whole nor any part of the information contained in, or the product described in this manual, may be adapted or reproduced in any material or electronic form without the prior written consent of the copyright holder. This product and its documentation are supplied on an as-is basis and no warranty as to their suitability for any particular purpose is either made or implied. ASiKS-Engineering will not accept any claim for damages howsoever arising as a result of use or failure of this product. Your statutory rights are not affected. This product or any variant of it is not intended for use in any medical appliance, device or system in which the failure of the product might reasonably be expected to result in personal injury. This document provides preliminary information that may be subject to change without notice. No freedom to use patents or other intellectual property rights is implied by the publication of this document.

## Appendix A – Revision History

### Revision History

- 1.0 Initial Release 22<sup>nd</sup> February, 2006
- 2.0 User manual rework 15<sup>th</sup> January 2019